


Before using this unit, carefully read the sections entitled: "USING THE UNIT SAFELY" and "IMPORTANT NOTES" (supplied on a separate sheet). After reading, keep the document(s) where it will be available for immediate reference.

Panel Descriptions



For more information, refer to "Reference Manual" (PDF).

1. Access the following URL.
<http://www.boss.info/manuals/>
2. Choose "RC-5" as the product name.

Name	Explanation												
1 DC IN jack	Accepts connection of an AC Adaptor (PSA series; sold separately). By using an AC Adaptor, you can play without being concerned about how much battery power you have left. * Use only the specified AC adaptor (PSA-series). * If the AC adaptor is connected while a battery is installed, the power supply is drawn from the AC adaptor.												
2 Display	Shows various information of the RC-5. During recording/playback/overdubbing, the color of the screen changes according to the status. <table border="1"> <tr> <td>Lit blue</td> <td>No phrase</td> <td>Lit yellow</td> <td>Overdubbing</td> </tr> <tr> <td>Lit red</td> <td>Recording</td> <td>Lit white</td> <td>Phrase exists</td> </tr> <tr> <td>Lit green</td> <td>Playing</td> <td></td> <td></td> </tr> </table> * Never strike or apply strong pressure to the display.	Lit blue	No phrase	Lit yellow	Overdubbing	Lit red	Recording	Lit white	Phrase exists	Lit green	Playing		
Lit blue	No phrase	Lit yellow	Overdubbing										
Lit red	Recording	Lit white	Phrase exists										
Lit green	Playing												
3 [MEMORY/LOOP LEVEL] knob	<table border="1"> <tr> <td rowspan="2">Play screen (*)</td> <td>Turning</td> <td>Selects a memory (1–99) or adjusts the volume of the track.</td> </tr> <tr> <td>Pressing</td> <td>Switches between selecting a memory and adjusting the volume of the track.</td> </tr> <tr> <td rowspan="2">When editing</td> <td>Turning</td> <td>Selects a parameter or changes a value.</td> </tr> <tr> <td>Pressing</td> <td>Specifies the parameter to edit. Alternatively, confirms an operation.</td> </tr> </table> (*) The screen that appears after you turn on the power is called the "Play screen." <table border="1"> <tr> <td>Turn while pressing</td> <td>Changes a value in larger steps.</td> </tr> </table>	Play screen (*)	Turning	Selects a memory (1–99) or adjusts the volume of the track.	Pressing	Switches between selecting a memory and adjusting the volume of the track.	When editing	Turning	Selects a parameter or changes a value.	Pressing	Specifies the parameter to edit. Alternatively, confirms an operation.	Turn while pressing	Changes a value in larger steps.
Play screen (*)	Turning		Selects a memory (1–99) or adjusts the volume of the track.										
	Pressing	Switches between selecting a memory and adjusting the volume of the track.											
When editing	Turning	Selects a parameter or changes a value.											
	Pressing	Specifies the parameter to edit. Alternatively, confirms an operation.											
Turn while pressing	Changes a value in larger steps.												
4 RHYTHM [TEMPO] button	Press to specify the tempo (40.0–300.0) of the rhythm. You can also set the tempo by pressing the button at the desired interval (tap tempo).												
5 RHYTHM [ON/OFF] button	Sounding a rhythm The rhythm switches on (lit)/off (unlit)/ready to play rhythm (blink)c each time you press the button. You can record while listening to a rhythm at the tempo you specify. Long-press the button (two seconds or longer) to select rhythm settings mode.												
6 [SETUP] button	Lets you make settings that affect the entire RC-5 (the function of a footswitch or expression pedal connected to this unit, and system settings).												
7 [MEMORY] button	Lets you make settings related to loop playback and recording, rhythm settings, and memory name settings. If the track of the selected memory is already recorded, the button is lit green.												

By pressing the [SETUP] button and [MEMORY] button simultaneously, you can save a memory (write) or erase (clear) memory data.

Name	Explanation
8 OUTPUT jacks A (MONO), B	Connect these jacks to your amp or monitor speakers. If you're using a mono setup, use only the A (MONO) jack. Even sound that is input in stereo is output in mono. Turning the power on/off The OUTPUT A (MONO) jack doubles as the power switch. Power to the unit is turned on when you plug into the OUTPUT A (MONO) jack; the power is turned off when the cable is unplugged.
9 STOP/MEMORY SHIFT jack	Connect a separately sold footswitch or expression pedal to this jack. This lets you control a variety of functions: you can use a footswitch to stop recording/playback/overdubbing or to switch memories, and you can use an expression pedal to operate various parameters. * Use only the specified expression pedal (FV-500H, FV-500L, EV-30, and Roland EV-5; sold separately). By connecting any other expression pedals, you risk causing malfunction and/or damage to the unit. NOTE When connecting an external pedal, you must turn off the power before connecting or disconnecting cables. Failure to observe this precaution will cause malfunctions.
10 INPUT jacks A (MONO), B	Connect your guitar/bass or effect unit to these jacks. Use the A (MONO) jack and B jack when connecting a stereo-output effects unit. Use only the A (MONO) jack if you're using a mono source.
11 Pedal switch	This pedal switches you between phrase recording, playback, and overdubbing. Press the pedal twice in succession to stop playback. Undo/Redo Hold down the pedal two seconds or longer during playback or overdubbing to Undo (cancel the recording or the last overdubbing). Hold down the switch once again for two seconds or longer to Redo (cancel the Undo). Clear Hold down the pedal two seconds or longer while stopped, the recorded phrase is cleared.
12 Thumbscrew	When this screw is loosened, the pedal will open, allowing you to change the battery. → "Changing the Battery"
13 MIDI IN, OUT connectors	Connect an external MIDI device here. To make these connections, use TRS/MIDI connecting cables (sold separately: BMIDI-5-35). This lets you control an external MIDI device from this unit via MIDI.
14 USB port	You can connect your computer here and use it to back up or recover data.

Connections

- To prevent malfunction and equipment failure, always turn down the volume, and turn off all the units before making any connections.
- Do not use connection cables that contain a built-in resistor.
- Before turning the unit on/off, always be sure to turn the volume down. Even with the volume turned down, you might hear some sound when switching the unit on/off. However, this is normal and does not indicate a malfunction.

- Even if batteries are installed, the unit will turn off if you connect or disconnect the power cord from the AC outlet while the unit is turned on, or if you connect or disconnect the AC adaptor from the unit. When this occurs, unsaved data may be lost. You must turn off the power before you connect or disconnect the power cord or AC adaptor.

Basic Operation


Getting ready to record

Turn the [MEMORY/LOOP LEVEL] knob to select a memory (1–99).

01 Memory	01
Memory number	Memory name

Screen	Status	Track:
Blue	Empty track	Record and play back audio from an instrument such as guitar.
White	Track contains data	Memory: The one track, together with the "rhythm" settings, are collectively called a "memory." The RC-5 can store up to 99 memories.

Creating a loop phrase



- NOTE**
- The maximum recording time is approximately 1.5 hours for one track, and approximately 13 hours total for all memories. If you exceed the maximum recording time, recording or overdubbing ends at that point, and the unit switches to loop playback.
 - Roland assumes no liability concerning the restoration of any stored content that has been lost.

Technique for stopping




Stop

Screen: Lit white
During overdubbing or loop playback, you can stop by pressing the pedal twice in succession.
* Press the pedal twice within one second.

Saving a Memory (WRITE)

If you select a different memory or turn off the power after recording or editing the settings, the recorded content or edited settings will be lost. If you want to keep the data, you must save it.

1. Press the [SETUP] button and [MEMORY] button simultaneously. The UTILITY screen appears.



2. Turn the [MEMORY/LOOP LEVEL] knob to select "WRITE," and press the [MEMORY/LOOP LEVEL] knob.

3. Turn the [MEMORY/LOOP LEVEL] knob to select the save-destination memory. This procedure is not required if the memory number is acceptable as is. If you decide to cancel, press one of the RHYTHM [TEMPO]–[MEMORY] buttons.

4. Press the [MEMORY/LOOP LEVEL] knob. The memory will be saved.

Settings for the Entire RC-5 (SETUP)

1. Press the [SETUP] button. The SETUP screen appears.



2. Turn the [MEMORY/LOOP LEVEL] knob to select the item that you want to edit, and press the [MEMORY/LOOP LEVEL] knob.



3. Turn the [MEMORY/LOOP LEVEL] knob to select the parameter that you want to edit, and press the [MEMORY/LOOP LEVEL] knob.




4. Turn the [MEMORY/LOOP LEVEL] knob to change the value.
5. Press the [SETUP] button to return to the play screen.

Use of Battery

- Batteries should always be installed or replaced before connecting any other devices. This way, you can prevent malfunction and damage.
- If operating this unit on batteries, please use alkaline batteries.
- If you handle batteries improperly, you risk explosion and fluid leakage. Make sure that you carefully observe all of the items related to batteries that are listed in "USING THE UNIT SAFELY" and "IMPORTANT NOTES" (supplied on a separate sheet).

Changing the Battery

1. Hold down the pedal and loosen the thumbscrew **1**, then open the pedal **2** upward.
* The pedal can be opened without detaching the thumbscrew completely.
2. Remove the old battery from the battery housing **3**, and remove the battery snap **4** connected to it.
3. Connect the battery snap to the new battery, and place the battery inside the battery housing.
* Be sure to carefully observe the battery's polarity (+ versus -).
4. Slip the coil spring **5** onto the spring base **6** on the back of the pedal, and then close the pedal.
* Carefully avoid getting the battery snap cord **7** caught in the pedal, coil spring, and battery housing.
5. Insert the thumbscrew into the guide bush hole **8** and tighten it securely.



Main Specifications

Power Supply	Alkaline battery (9V, 6LR61 or 6LF22) AC adaptor (PSA series; sold separately)
Current Draw	170 mA * Expected battery life under continuous use (These figures will vary depending on the actual conditions of use.) Alkaline: Approx. 2 hours
Dimensions	73 (W) x 129 (D) x 56 (H) mm 2-7/8 (W) x 5-1/8 (D) x 2-1/4 (H) inches
Weight	450 g/1 lb (including battery)
Accessories	Owner's Manual, Leaflet ("USING THE UNIT SAFELY"/"IMPORTANT NOTES," and "Information"), Alkaline battery (9V, 6LR61 or 6LF22)
Options (sold separately)	AC adaptor: PSA series Footswitch: FS-5U Dual Footswitch: FS-6, FS-7 Expression Pedal: FV-500H, FV-500L, EV-30, Roland EV-5 TRS/MIDI connecting cable: BMIDI-5-35

* 0 dBu = 0.775 Vrms
* This document explains the specifications of the product at the time that the document was issued. For the latest information, refer to the Roland website.

SUPPLIER'S DECLARATION OF CONFORMITY Compliance Information Statement

Model Name : RC-5
Type of Equipment : Guitar Effects
Responsible Party : Roland Corporation U.S.
Address : 5100 S. Eastern Avenue Los Angeles, CA 90040-2938
Telephone : (323) 890-3700

For the USA