

MIDI Implementation Chart

Function	Transmitted	Recognized	Remarks	
Basic Channel	Default Changed	1-16 1-16	1-16 1-16	Memorized
Mode	Default Messages Altered	x x *****	Mode 3 x	
Note Number	: True Voice	0-127 *****	0-127 0-127	
Velocity	Note On Note Off	o o	o o	
After Touch	Key's Channel's	x x	o o	
Pitch Bend		x	o	
Control Change		1 x 5 x 7 x 10 x 11 x 64 x 65 x 66 x 67 x 68 x 71 x 72 x 73 x 74 x 75 x 76 x 77 x 78 x 80 o 81 o 82 o 83 o 84 x 91 x 92 x	o o	Modulation Portamento Time Volume Panpot Expression Hold 1 Portamento Sostenuto Soft Legato Foot Switch Resonance Release Time Attack time Cutoff Decay Time Vibrato Rate Vibrato Depth Vibrato Delay FILTER Knob MOD Knob FX Knob SOUND Knob *1 Portamento control General Purpose Effect 1 (Reverb Send Level) General Purpose Effect 3 (Chorus Send Level)
Program Change	: True Number	x *****	x *****	
System Exclusive		x	x	
System Commor	: Song Position : Song Select : Tune Request	x x x	x x x	
System Real Time	: Clock : Start : Continue : Stop	o o x o	o o o o	
Aux Message	: All Sound Off : Reset All Controllers : All Notes Off : Omni Mode Off : Omni Mode On : Mono Mode On : Poly Mode On	x x x x x x x	o o o o o o o	
Notes	*1 for MC-101 compatibility.			

Mode 1: Omni On, Poly
Mode 3: Omni Off, Poly

Mode 2: Omni On, Mono
Mode 4: Omni Off, Mono

o: Yes
x: No