

# Functionality Added to the TB-03 (Ver. 1.04)

This document explains the functionality that has been added to the TB-03. Read it together with the Owner's Manual.

## Pattern Write

### Copying a Pattern

This function copies a pattern.

\* The copy-destination pattern is overwritten.

1. Select pattern write mode.
2. Select the copy-source pattern.
3. Hold down the **17**[FUNCTION] button and press **19** keyboard button [F#].
4. Select the copy-destination pattern.
5. Press the **23**[WRITE/NEXT] button to execute the copy.

### Random Pattern 1

This function generates a random pattern in the current pattern number.

\* The current pattern is overwritten.

1. Select pattern write mode.
2. Select a pattern.
3. Hold down **17**[FUNCTION] button and press **19** keyboard button [G#].

### Random Pattern 2

This function randomly changes the octave shift, slide, and accent of the current pattern.

This lets you create a variation without changing the key of the pattern.

\* The current pattern is overwritten.

1. Select pattern write mode.
2. Select a pattern.
3. Hold down **17**[FUNCTION] button and press **19** keyboard button [A#].